



Digital Mixer Amplifier with Multimedia Player 500W

FRONT PANEL



- 1. MIC1 IN
- 2. USB Port
- 3. MIC1 Volume Control
- 4. MIC2 Volume Control
- 5. Mode Button
- 6. MIC3/AUX2 Volume Control
- 7. Play/Pause Button
- 8. Previous Song / (Previous Radio in FM)
- 9. Display Screen
- 10. Next Song / (Next Radio in FM)
- 11. AUX1 Volume Control
- 12. Chime 1 Button
- 13. Chime 2 Button
- 14. BASS Volume Control
- 15. TREBLE Volume Control
- 16. LEVEL LED
- 17. MASTER Volume Control
- 18. POWER LED
- 19. POWER

REAR PANEL



- 1. DC+24V Power IN (EMC Power IN, can only output 60W)
- 2. Power IN AC110-240V
- 3. Constant Resistance and Constant Voltage Output End
- 4. Extended Preamplifier Interface
- 5. AUX OUT
- 6. AUX1 IN and AUX2 IN
- 7. Audio Source Selection Switch
- 8. MIC Gain Control
- 9. MIC2 and MIC3 Balanced IN
- 10. Phantom Power Switch
- 11. EMC Trigger IN
- 12. MUTE Short Circuit Trigger
- 13. SIREN Short Circuit Trigger
- 14. Alarm Gain Control
- 15. FM Antenna
- 16. Constant-resistance and Constant-voltage Switch(Can switch to 4-16Ω or 100V)
- 17. AC Power Switch (Can switch voltage)

ORDERING INFORMATION

Part Number	Description	Standard Quantity
NVS-90330501MA	Digital Mixer Amplifier with Multimedia Player 500W	01