



Digital Mixer Amplifier with Multimedia Player 650W

FRONT PANEL



- | | |
|--|---|
| <ul style="list-style-type: none"> 1. MIC1 IN 2. USB Port 3. MIC1 Volume Control 4. MIC2 Volume Control 5. Mode Button 6. MIC3/AUX2 Volume Control 7. Play/Pause Button 8. Previous Song 9. Display Screen 10. Next Song | <ul style="list-style-type: none"> 11. AUX1 Volume Control 12. Chime 1 Button 13. Chime 2 Button 14. BASS Volume Control 15. TREBLE Volume Control 16. LEVEL LED 17. MASTER Volume Control 18. POWER LED 19. POWER |
|--|---|

REAR PANEL



- | | |
|--|---|
| <ul style="list-style-type: none"> 1. DC +24 Power IN 2. Power IN Socket 3. Constant Resistance and constant voltage output end 4. Extended Pre-amplifier Interface 5. AUX OUT 6. AUX1 IN and AUX2 IN 7. Audio Source Selection Switch 8. MIC Gain Control 9. MIC2 and MIC3 Balanced IN | <ul style="list-style-type: none"> 10. Phantom Power Switch 11. EMC Trigger IN 12. MUTE Short Circuit Trigger 13. SIREN Short Circuit Trigger 14. Alarm Gain Control 15. FM Antenna 16. Constant resistance & constant voltage switch 17. AC Power Switch |
|--|---|

Digital Mixer Amplifier with Multimedia Player 650W

ORDERING INFORMATION

Part Number	Description	Standard Quantity
NVS-90340651MA	Digital Mixer Amplifier with Multimedia Player 650W	01

ACCESSORIES INFORMATION

Description	Standard Quantity
FM Antenna	01
Remote Controller	01
Power Cord	01
6P Green Plug with Lock	01
2-pin RCA SC Cap	01
Handle	02
Plastic Washer	04
Cross Recessed Countersunk Head Screw Black /3x8	04
Cross Recessed Raised Countersunk Head Screw Black /5x19	04
User Manual	01
Warranty Card	01
Certificate	01